

gem

E 1400

11/2011

S 993

H09550W686085

JF

OPERATORS STATION	OK	NOT OK	COMMENTS
Walker Plugging Light + Buzzer (M)	()	()	
Ground Speed Indicator	[X]	[]	
Lights	[X]	[]	
Cab filters	[]	[]	
Cab door, latches	[X]	[]	
Winshield wiper	[X]	[]	
Blower fan	[X]	[]	
Air conditioning, heater	[X]	[]	
Corner post gauges	[X]	[]	
Low shaft speed monitor	[X]	[]	
HarvesTrak monitor	[X]	[]	
Overhead Instrument Panel	[X]	[]	
Parking Brake	[X]	[]	
Brake Petal	[X]	[]	
Armrest Panel Switches	[X]	[]	
Reel Speed Motor	(M)	()	
<u>SEPARATOR</u>			
Clean Sieve + Chaffer (M)	(M)	()	
Belts & Chains	[X]	[]	
Separator Speeds	[X]	[]	
Intermediate sheave Gap	[X]	[]	
StrawWalker Gearcase Bolt	[X]	[]	
Rasp Bars ^{And Inserts}	[X]	[]	
Concave ^{1 Row IN 1 Row out}	[X]	[]	
Beater Grate	[X]	[]	
Straw Walker Bearings	[X]	[]	
Clean Grain Sprockets	[X]	[]	
Clean Grain Chain	[X]	[]	
Tailings Chains	[X]	[]	
Tailings Sprockets	[X]	[]	
Upper Tailings Paddles	[X]	[]	
Shoe Supply Bearings	[X]	[]	Replaced 3 + brush Hub
Separator Drive U-joints	[X]	[]	
Concave knock-out Plugs	[X]	[]	
Unload Auger Limit Switch	[X]	[]	
Cleaning Fan Operation	[X]	[]	
Unloading Auger Belts	[X]	[]	
Straw Chopper Belts	[X]	[]	
Straw chopper - Chaff spreader (M)	(M)	()	
<u>FEEDER HOUSE</u>			
Reverser Operation	[X]	[]	
Chain Tension	[X]	[]	Took 1/2 Link out
Drum Bearings	[X]	[]	
Upper Shaft & Sprockets	[X]	[]	
Front Paddles (Sidehill)	[]	[]	
Upper Sheave Bearings	[X]	[]	
Feeder House Floor	[X]	[]	

11-21-11
9550
Combine
SERVICE

COMMENTS:

STS Concave Bushings ()
 Replaced Front Sho Auger Drive shaft / Bearings / Hub
 Put new concave Rod and cal it to 0
 Found seals out ~~in~~ Feeder House Speed Piston Replaced Seals

HYDRAULIC SYSTEM	OK	NOT OK	COMMENTS
Valve Stack Operation	X	[]	_____
Hydraulic Leaks	X	[]	_____
Leveling System	X	[]	_____
Steering Cylinders	X	[]	_____
Steering Valve	X	[]	_____
Feeder House Leak Down ?	X	[]	_____
<u>POWER TRAIN</u>			
Hydro Cable Adjustment	X	[]	_____
Final Drive Leakage	X	[]	_____
Sidehill Pivot Bushings	X	[]	_____
Sidehill Frame Cracked	X	[]	_____
Tire - Air Pressure	X	()	_____
<u>ELECTRICAL</u>			
Central Electronics Box Clean and Dry		X	
Battery & Cables	X	[]	_____
Seat Safety Switch	X	[]	_____
Starter Operation	X	[]	_____
Neutral Start Switch	X	[]	_____
Alternator Pulley & Belt	X	[]	_____
Clear Codes	()		
<u>COOLING SYSTEM</u>			
Coolant	X	[]	good = 25° F
Radiator Core Condition	X	[]	_____
Radiator Cap	X	[]	_____
Fan/Belt/Pulley	X	[]	_____
Hoses	X	[]	_____
Rotary Screen & Belt	X	[]	_____
Water Pump	X	()	_____
<u>ENGINE & FUEL SYSTEM</u>			
Fan Bearing	X	[]	_____
Intake Hoses	X	[]	_____
Exhaust System	X	[]	_____
Turbo Oil Line	X	[]	_____
Low/High Idle Speeds	X	[]	_____
Injection Pump Leaks	X	[]	_____
Nozzles & lines	X	[]	_____
Transfer Pump	X	[]	_____
<u>MISCELLANEOUS</u>			
Correct O.P. manuals in Cab	(X)		
Ladder Operation	X	[]	_____
Mirrors	X	[]	_____
SMV Emblem	X	[]	_____
<u>COMMENTS:</u>			
Changed Clean Grain Belt			
Secondary Belt			
Converter Husen Belt			
Header Clutch Belt			
All Had Deep Cuts In the Belt			
* Note If u take Spring Pressure off Belt's during off season they will last longer just to let u know			

FLUID LEVELS

OK

NOT OK

	OK	NOT OK	
Grease Reel Pump Bearings	<input checked="" type="checkbox"/>		
Engine Oil	<input checked="" type="checkbox"/>	<input type="checkbox"/>	DID NOT change Filter
Engine Gearcase	<input checked="" type="checkbox"/>	<input type="checkbox"/>	DID NOT change Filter
Hydraulic Reservoir	<input type="checkbox"/>	<input type="checkbox"/>	
Radiator	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Straw Walker Gearcase	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Reverser	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Dual Range	<input type="checkbox"/>	<input type="checkbox"/>	
Primary Countershaft Gearcase	<input type="checkbox"/>	<input type="checkbox"/>	
Loading Auger Gearcase	<input type="checkbox"/>	<input type="checkbox"/>	
Transmission	<input type="checkbox"/>	<input type="checkbox"/>	
Final Drives	<input type="checkbox"/>	<input type="checkbox"/>	
Brake Reservoir	<input type="checkbox"/>	<input type="checkbox"/>	

Grease Entire Machine

COMMENTS: Vertical unload Gearbox

Vertical unloading Auger

Horizontal unloading Auger

Clean Grain Lower Auger

Grain Tank Loading Auger

Air Cond. Compressor Mount

? Holes in Bottom of Grain Tank

Greenstar

Grease Intermediate Drive in fastest Setting

Moisture Sensor Working Put upstairs & Tag

Fire Ext. Charged

* DID NOT change any Fluids or Filters



Farmers Supply Sales, Inc.

1409 "E" Ave - Hwy 22 East
P.O. Box 1205
Kalona, IA 52247
319-656-2291

JOHN DEERE

Hwy 6 East
P.O. Box 137
West Liberty, IA 52776
319-627-4323

Ship To :

SAME AS BELOW

Invoice To :

K-L GENT, INC.
% KEVIN GENT
1930 180TH STREET
WELLMAN, IA 52356

Branch KALONA		*REPRINT*	
Date 12/11/12	Time 09:00:08 (B)	Page 01	
Account No. GENT006	Phone No. 319 6982205	Invoice No. S72913	
Ship Via	Purchase Order		
Sales Tax Licence No.	Federal Exemption No.		
			Salesperson NDC

DESCRIPTION

STK#/FLEET#		HRS	PIN/EIN	WARRANTY DATE	HRS
Z001562	JD 9550 COMBINE	1530	H09550W686085		
	9550	1088	RG6081H114471		

REPAIR# 01 C 107 9550-6081 11/16/12 11/16/12

SERVICE

CHANGED ENGINE OIL AND FILTER. REPLACED FUEL FILTER AND WATER SEPERATOR FILTER. REPLACED ENGINE AIR FILTERS AND CAB FILTERS. CHANGED HYDRAULIC OIL FILTERS. CHECKED ALL FLUID LEVELS AND TIRE AIR PRESSURES. CHECKED LIGHTS AND SWITCHES OPERATION. CHECKED ALL BELTS AND CHAINS TIGHTEN PADDLE CHAINS AND CROSS AUGER CHAIN REPLACED BUSHING IN COUNTER SHAFT FLIPPED CHOPPER KNIVES AND HAMMERS TIGHTEN FEEDER HOUSE CONVEYOR CHAIN REPLACED BEARINGS IN REEL PUMP REPLACED AUGER BOOT CHECKED FOR LEAKS IN TURBO, DID NOT FIND ANY NOISE WAS COMING FROM REEL PUMP BEARINGS

12-11-12

AH106110	SEAL	2	10.37	20.74
AH115833	FILTER	1	60.91	60.91
AH115836	FILTER	1	67.05	67.05
AH128449	FILTER	3	54.96	164.88
AH148880	ELEMENT	1	82.16	82.16
AH166638	LINK	1	5.30	5.30
AH166639	LINK	1	4.54	4.54
AH201530	BEARING	1	29.52	29.52
AH201531	BEARING	1	48.19	48.19
AR86745	FILTER	1	20.81	20.81
B3118R	SNAP RING	2	4.04	8.08
EPA	WASTE OIL	8	.15	1.20
FILTER CRUSH	DISPOSAL CHRGE	4	.50	2.00
H125528	BUSHING	2	27.60	55.20
H149780	SPOUT	1	56.66	56.66
H164018	LIMIT CURTAIN	1	11.30	11.30

CONTINUED ON PAGE 02

X _____
Signature Date

THIS PURCHASE IS SUBJECT TO TERMS OF THE FARMPLAN CREDIT AGREEMENT. PURCHASES PROCESSED THROUGH FARMPLAN ARE DUE ON RECEIPT OF INVOICE. SPECIAL ORDER GOODS ARE NOT REFUNDABLE ALL REFUNDS MUST BE ACCOMPANIED BY THIS INVOICE, RETURN GOODS ARE SUBJECT TO A 15% RESTOCKING CHARGE. TITLE TO ALL ITEMS REMAINS WITH FARMERS SUPPLY SALES INC. UNTIL PURCHASE PRICE, INTEREST AND OTHER CHARGES ARE FULLY PAID. SERVICE CHARGE ON OVERDUE ACCOUNTS AT THE RATE OF 1.5% PER MONTH (18% PER ANNUM). MINIMUM SERVICE CHARGE 1.00

IN THE CASE OF A WORK ORDER I HEREBY AUTHORIZE THE ABOVE WORK TO BE DONE ALONG WITH THE USE OF NECESSARY MATERIALS. YOU AND YOUR EMPLOYEES MAY OPERATE THE ABOVE MACHINE FOR PURPOSES OF TESTING. INSPECTION OR DELIVERY AT MY RISK. I AGREE TO PAY CASH ON DELIVERY OF MACHINE OR ON TERMS SATISFACTORY WITH YOU UNTIL PAID IN FULL. IT IS UNDERSTOOD THAT THIS COMPANY ASSUMES NO RESPONSIBILITY FOR LOSS OR DAMAGE BY THEFT OR FIRE TO MACHINE PLACED WITH THEM FOR STORAGE, SALE, REPAIR OR WHILE FIELD TESTING.



JOHN DEERE

Farmers Supply Sales, Inc.

1409 "E" Ave - Hwy 22 East
P.O. Box 1205
Kalona, IA 52247
319-656-2291

Hwy 6 East
P.O. Box 137
West Liberty, IA 52776
319-627-4323

Ship To :

SAME AS BELOW

Invoice To :

K-L GENT, INC.
% KEVIN GENT
1930 180TH STREET
WELLMAN, IA 52356

Branch KALONA		
Date 12/11/12	Time 09:00:08 (B)	Page 02
Account No. GENT006	Phone No. 319 6982205	Invoice No. S72913
Ship Via	Purchase Order	
Sales Tax Licence No.	Federal Exemption No.	
		Salesperson NDC

DESCRIPTION

STK#/FLEET#		HRS	PIN/EIN	WARRANTY DATE	HRS
Z001562	JD 9550 COMBINE	1530	H09550W686085		
	9550	1088	RG6081H114471		
LOW VIS	OIL	4	4.26		17.04
RE500186	FUEL FILTER	1	32.31		32.31
RE57394	FILTER	1	16.20		16.20
RE63932	FILTER	1	68.13		68.13
SW60COUS	LINK (60)	1	2.00		2.00
SW60HCOUS	LINK	1	3.71		3.71
TG15-40+50	TORQ GUARD +50	30	4.39		131.70
			PARTS		909.63
			LABOR	276.00	2054.13
10900	3990140		REPAIR TOTAL==>	276.00	2963.76
**** WORK ORDER TOTALS ****					
			INTERNAL		CUSTOMER
			PARTS		909.63
			LABOR	276.00	2054.13
			SHOP SUPPLIES		20.00
			SUB TOTAL==>	276.00	2983.76
			TAX 6.0 %		133.56
			WASHINGTON LOST TX		22.26
			INTERNAL TOTAL	276.00	
926677			TOTAL FARM PLAN		3139.58

12-11-12

X _____
Signature Date

THIS PURCHASE IS SUBJECT TO TERMS OF THE FARMPLAN CREDIT AGREEMENT. PURCHASES PROCESSED THROUGH FARMPLAN ARE DUE ON RECEIPT OF INVOICE. SPECIAL ORDER GOODS ARE NOT REFUNDABLE ALL REFUNDS MUST BE ACCOMPANIED BY THIS INVOICE, RETURN GOODS ARE SUBJECT TO A 15% RESTOCKING CHARGE. TITLE TO ALL ITEMS REMAINS WITH FARMERS SUPPLY SALES INC. UNTIL PURCHASE PRICE, INTEREST AND OTHER CHARGES ARE FULLY PAID. SERVICE CHARGE ON OVERDUE ACCOUNTS AT THE RATE OF 1.5 % PER MONTH (18 % PER ANNUM). MINIMUM SERVICE CHARGE 1.00

IN THE CASE OF A WORK ORDER I HEREBY AUTHORIZE THE ABOVE WORK TO BE DONE ALONG WITH THE USE OF NECESSARY MATERIALS. YOU AND YOUR EMPLOYEES MAY OPERATE THE ABOVE MACHINE FOR PURPOSES OF TESTING. INSPECTION OR DELIVERY AT MY RISK. I AGREE TO PAY CASH ON DELIVERY OF MACHINE OR ON TERMS SATISFACTORY WITH YOU UNTIL PAID IN FULL. IT IS UNDERSTOOD THAT THIS COMPANY ASSUMES NO RESPONSIBILITY FOR LOSS OR DAMAGE BY THEFT OR FIRE TO MACHINE PLACED WITH THEM FOR STORAGE, SALE, REPAIR OR WHILE FIELD TESTING.

OPERATORS STATION	OK	NOT OK	COMMENTS
Walker Plugging Light + Buzzer	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Ground Speed Indicator	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Lights	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Cab filters	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Change
Cab door, latches	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Windshield wiper	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Blower fan	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Air conditioning, heater	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Corner post gauges	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Low shaft speed monitor	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
HarvesTrak monitor	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Overhead Instrument Panel	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Parking Brake	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Brake Petal	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Armrest Panel Switches	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Reel Speed Motor	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
<u>SEPARATOR</u>			
Clean Sieve + Chaffer	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Belts & Chains	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
Separator Speeds	<input type="checkbox"/>	<input type="checkbox"/>	
Intermediate sheave Gap	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Straw Walker Gearcase Bolt	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Rasp Bars And Inserts	<input type="checkbox"/>	<input type="checkbox"/>	
Concave 1 Row IN 1 Row out	<input type="checkbox"/>	<input type="checkbox"/>	
Beater Grate	<input type="checkbox"/>	<input type="checkbox"/>	
Straw Walker Bearings	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Clean Grain Sprockets	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Clean Grain Chain	<input type="checkbox"/>	<input checked="" type="checkbox"/>	tighten
Tailings Chains	<input type="checkbox"/>	<input checked="" type="checkbox"/>	tighten
Tailings Sprockets	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Upper Tailings Paddles	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Shoe Supply Bearings	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Separator Drive U-joints	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Concave knock-out Plugs	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Unload Auger Limit Switch	<input type="checkbox"/>	<input checked="" type="checkbox"/>	stops
Cleaning Fan Operation	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Unloading Auger Belts	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Straw Chopper Belts	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Straw chopper - chaff spreader	<input type="checkbox"/>	<input checked="" type="checkbox"/>	Flip knives
<u>FEEDER HOUSE</u>			
Reverser Operation	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Chain Tension	<input type="checkbox"/>	<input checked="" type="checkbox"/>	tighten
Drum Bearings	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Upper Shaft & Sprockets	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Front Paddles (Sidehill)	<input type="checkbox"/>	<input type="checkbox"/>	
Upper Sheave Bearings	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Feeder House Floor	<input checked="" type="checkbox"/>	<input type="checkbox"/>	

COMMENTS:

STS Concave Bushings ()

E1531 Sep 1088

11/15/12

HYDRAULIC SYSTEM	OK	NOT OK	COMMENTS
------------------	----	--------	----------

Valve Stack Operation	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Hydraulic Leaks	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Leveling System	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Steering Cylinders	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Steering Valve	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Feeder House Leak Down ?	<input checked="" type="checkbox"/>		

POWER TRAIN

Hydro Cable Adjustment	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Final Drive Leakage	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Sidehill Pivot Bushings	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Sidehill Frame Cracked	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Tire - Air Pressure	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____

ELECTRICAL

Central Electronics Box Clean and Dry		<input checked="" type="checkbox"/>	
Battery & Cables	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Seat Safety Switch	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Starter Operation	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Neutral Start Switch	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Alternator Pulley & Belt	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Clear Codes	<input checked="" type="checkbox"/>		

COOLING SYSTEM

Coolant	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Radiator Core Condition	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Radiator Cap	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Fan/Belt/Pulley	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Hoses	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Rotary Screen & Belt	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Water Pump	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____

ENGINE & FUEL SYSTEM

Fan Bearing	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Intake Hoses	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Exhaust System	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Turbo Oil Line	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Low/High Idle Speeds	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Injection Pump Leaks	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Nozzles & lines	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Transfer Pump	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____

MISCELLANEOUS

Correct op. Manuals in Cab	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Ladder Operation	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
Mirrors	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____
SMV Emblem	<input checked="" type="checkbox"/>	<input type="checkbox"/>	_____

COMMENTS:

FLUID LEVELS

OK

NOT OK

	OK	NOT OK	
Grease Reel Pump Bearings	<input checked="" type="checkbox"/>		
Engine Oil	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Change
Engine Gearcase	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Hydraulic Reservoir	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Radiator	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Straw Walker Gearcase	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Reverser	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Dual Range	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Primary Countershaft Gearcase	<input type="checkbox"/>	<input type="checkbox"/>	
Loading Auger Gearcase	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Transmission	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Final Drives	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Brake Reservoir	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
Grease Entire Machine	<input type="checkbox"/>		

COMMENTS: Vertical unload Gearbox

Vertical unloading Auger

Horizontal unloading Auger

Clean Grain Lower Auger

Grain Tank Loading Auger

Air Cond. Compressor Mount

? Holes in Bottom of Grain Tank

Greenstar

Grease Intermediate Drive in fastest Setting

Moisture Sensor Working Put upstairs & Tag

Fire Ext. Charged